


Lesson: Create a Machine Configuration

In this lesson, you'll create a custom machine to make sure that Fusion 360's calculations are appropriate for a specific machine.


Learning Objectives

- Modify a machine configuration.




The completed exercise


1. Continue with the *CAM Milling Setup* file from the previous module.



2. Additional parameters for a machine can be configured inside Fusion 360. If any operations exceed the machine's limits, Fusion 360 will prompt a warning to identify that the machine's capabilities have been exceeded. Edit the Browser's CAM Milling Setup1.




- Click the dialog's Select inside the Machine section.



- Open the supplied *Haas VM-3 Specifications* Excel file and keep it available for reference. The values in this Excel file will be used to populate a custom machine's parameters. All the values in the file are sourced from the Haas website. Explore the file's contents.

HAAS VM 3 Specs	
Travel	inch
X Axis	40
Y Axis	26
Z Axis	25
Spindle	
Max Rating	30hp
Max Speed	12,000 rpm
Taper	CT or BT 40
Table	
Length	54
Width	24
T-slot width	0.63
T-slot center distance	3.94


- In the Machine Library dialog, choose the Fusion 360 Library option in the left column. Navigate to the Autodesk Generic 3-axis option and select it. Right-click the Generic 3-axis machine and choose Copy from the menu.



6. Decide whether you want to create the new machine in your local library or on the cloud. Activate this library in the dialog's left column. Paste the copied machine into your selected library. For the purposes of this document, the cloud library was selected.



7. Edit the new machine.




8. Navigate to the Machine Configuration dialog's Description section, then change the information to match the image on the right. Click the dialog's OK when you are finished.

Description
Description
3-axis
Model
VM-3
Vendor
HAAS
CNC control

9. The new information is updated in the library. Edit the new machine again.



10. Navigate to the Machine Configuration dialog's Dimensions section. Notice that the units are listed in metric. Choose the Inches option from the menu at the bottom of the dialog.



11. The Excel file does not list a specific width, height, and depth value. The Excel file's dimensions for shipping values can be used to populate these fields.

Dimensions	
Width	Weight
<input type="text" value="156 in"/>	<input type="text" value="15300 lb"/>
Height	
<input type="text" value="125 in"/>	
Depth	
<input type="text" value="102 in"/>	

12. Continue to the dialog's Capabilities section and use the Excel file to populate the various fields.

Capabilities	
<input checked="" type="checkbox"/> Milling	
<input type="checkbox"/> Turning	
<input type="checkbox"/> Cutting	
Tool changer	
<input checked="" type="checkbox"/> Automatic tool changer	
<input checked="" type="checkbox"/> Supports tool preload	
Number of tools	Maximum tool length
<input type="text" value="30"/>	<input type="text" value="13 in"/>
Maximum tool weight	Maximum tool diameter
<input type="text" value="12 lb"/>	<input type="text" value="5 in"/>
Motion	
Maximum feedrate	Maximum block per minute
<input type="text" value="710 in/min"/>	<input type="text" value="0"/>

13. Continue to the dialog's Workpiece section. These values are not shown in the Excel file but can be extrapolated from the machine's travel and table length dimensions. Use this information to populate the various fields.

Workpiece	
Maximum workpiece X	40 in
Maximum workpiece Y	26 in
Maximum workpiece Z	25 in
Weight capacity	4000 lb


14. Continue to the Kinematics> X Linear section and enter the Rapid feedrate and Max feedrate values. Note that these values are the overall feedrates and not the cutting feedrates. Also add these values to the Y Linear and Z Linear sections.

Linear Axis		
Coordinate	X	
Custom name		
Home position	0 in	
Resolution	0 in	
Rapid feedrate	700 in/min	
Max feedrate	710 in/min	
	X	Y
Offset	0 in	0 in
	Min	Max
Range	0 in	0 in

15. Continue to the Machining Time section and reduce the Tool change time to 3.6 s.

Machining Time	
Feedrate ratio (%)	100
Tool change time	3.6 s

- 16.** Continue to the Post Processing section and choose the `haas.cps` option from the Post-Processor menu. Click OK to accept all the parameters you entered and update the Haas VM-3 machine. If any values create an error, you will be prompted to fix the values before the dialog can be OKed.



- 17.** Click the Machine Library dialog's Select to choose this machine for the setup. Accept the changes. Save the file and continue to the next module.

